



60-2809


streetsentz
Common Sentz Tips For Safer Kidz



4-in-1 Puzzle Vehicle

You can assemble up to four different vehicles – a plane, helicopter, submarine, or a racecar! The transmitter controls vehicle movement from up to 50 feet away, and you can reach driving speeds of up to 45 feet per minute. Your vehicle comes in two frequencies (27 MHz and 49 MHz), so you and your friends can play together. Check the box to see which frequency you have. This toy is suitable for children ages 3 and up.

parts inventory



transmitter



Thank you for purchasing your 4-in-1 Puzzle Vehicle from RadioShack.

what's included

15 vehicle parts

transmitter

installing batteries

You will need four AA batteries to power your vehicle, and one 9-volt battery to power the transmitter (neither supplied).

In the transmitter

1. Remove the battery compartment cover and insert a 9V battery.
2. Replace the cover, securing it with the screw.



In the vehicle


1. Rotate **ON/OFF** to **OFF**.
2. Remove the battery compartment cover and insert four AA batteries.
3. Replace the cover, securing it with the screws.



driving your vehicle

Hold the transmitter straight up and as high as possible. Rotate **ON/OFF** on the vehicle to **ON**.

Release both buttons to brake and stop.



Hold down to drive your vehicle forward.

Hold down to drive in reverse (backward) and circle backwards.

vehicle designs

Assemble your own airplane to jet down the runway.



Build a sporty roadster for a day at the racetrack!



Configure a helicopter so you are ready to go anywhere!



Create this submarine for submerged sailing adventures!



helpful hints

- Running your vehicle for long periods of time can generate high heat levels, resulting in wear and tear on the motor. When the battery power dies in your vehicle, let the vehicle cool for 10 minutes before replacing the batteries.
- If the motor runs, but the vehicle does not respond to the transmitter, move the transmitter closer to the vehicle and try again.
- If someone is using a CB nearby, it may cause interference. Move your vehicle away from the CB.
- You cannot operate your vehicle near devices with transmitters that use the same frequency (27/49 MHz).
- Dispose of old batteries promptly and properly.
- Do not burn or bury batteries.
- Use only fresh batteries of the required size and recommended type.
- If you do not plan to use the vehicle for a week or more, remove the batteries. Batteries can leak chemicals that can damage electronic parts.

The FCC Wants You to Know

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult your local RadioShack store or an experienced radio/TV technician for help.
- If you cannot eliminate the interference, the FCC requires that you stop using your vehicle.
- Changes or modifications not expressly approved by RadioShack may cause interference and void the user's authority to operate the equipment.

limited 90-day warranty

This product is warranted by RadioShack against manufacturing defects in material and workmanship under normal use for ninety (90) days from the date of purchase from RadioShack company-owned stores and authorized RadioShack franchisees and dealers. For complete warranty details and exclusions, check with your local RadioShack store.

RadioShack Customer Relations
200 Taylor Street, 6th Floor, Fort Worth, TX 76102
04/04

